



Preparing your FinestraMiner.



1 Download App

Make sure your mobile phone is connected to Wifi and your Bluetooth is turned on. Download the Helium Hotspot App onto your phone.



2 Set up Helium account.

Open the Helium app and follow the setup instructions to set your account up. While setting up you will be shown 12 security keywords. Note them down using the included note card and pen and store safely. **You will need these to recover your account if you lose your password.**



3 Attach Antenna. Power Up.

Carefully screw on the included antenna into the jack on the side of FinestraMiner. Plug in the power cable into the base of FinestraMiner and plug it into the power supply. Plug the power supply into a wall outlet.



4 Connect FinestraMiner to Helium.

Using the Helium App, pair your phone with FinestraMiner. And then follow the instructions to connect FinestraMiner to the Helium Network.

Locating your FinestraMiner.



1 The FinestraMiner works best when it is placed near a window with minimal external obstructions.

Depending on the window, and availability of a power outlet, you may even attach it to a window pane using the adhesive base.

Follow the instructions in "Mounting your FinestraMiner".



2 Do not place the FinestraMiner near a metal mesh, screens or large metallic objects.

Water tanks or even large vehicles such as a truck parked outside could affect performance.

Also do try to ensure that any other electronic devices are placed a few feet away from FinestraMiner.

Mounting your FinestraMiner.



1 Peel it.

FinestraMiner comes equipped with a reusable adhesive base. This allows it to be placed in the most advantageous indoor locations for best performance - even sloping or vertical surfaces which are flat and smooth.



2 Stick it.

Activate the reusable backing by peeling off the protective covering - use tweezers if needed. Once removed press your FinestraMiner firmly against any flat smooth surface you planned to mount it on.


window



3 Remove it. Move it.

To remove or move your FinestraMiner just grasp the edges firmly and pull away with a twisting motion to lift one of the edges. Then pull away further to separate it from the surface. Do not try to forcibly pull FinestraMiner directly away from a surface - always pull back with a twisting motion.

window



4 Wipe each time.

Each time you remove FinestraMiner, wipe the adhesive backing with a clean damp cloth to refresh the stickiness. Make sure that backing is completely dry before use.



Support
thefinestra.com/support

Smart Mimic, FinestraMiner and the logos are the trademarks of Smart Mimic, Inc. Helium and the Helium logo are the trademarks of Helium, Inc. Apple and the Apple logo are trademarks of Apple Inc. Google Play and the Google Play logo are trademarks of Google LLC.

© Copyright 2021 Smart Mimic, Inc. All rights reserved.

SM-HW-BR-FN-01
Layout Version: 0.8



FINESTRAMiner